



Ref #	Part Number	Qty	Description
1	094163		Seat
2	028X23		Cap, Push On
3	094057		Spring
4	26X229		Screw
5	094160		Bolt, Wing
6	017X47 Z		Washer
7	009X56		Bolt, Shoulder
8	094154E700		Support, Seat
9	094156 Z		Rod, Pivot
10	094153E700		Bracket, Pivot
11	001X45		Bolt
12	015X89		Nut
13	009X55		Bolt, Shoulder
14	094155 Z		Washer
15	164X31		Spring
16	26X249		Screw
17	26X263		Screw
18	164X30		Spring
19	094150E276		Deck, Seat
20	015X88		Nut
21	094194E701		Plate, Index
22	009X47		Screw
23	094383		Mat, Left
24	094382		Mat, Right
25	094322E276		Hood
26	094087E701		Grille
27	094093		Lens, Left
28	094089 Z		Bezel, Left
29	094092		Lens, Right
30	094088 Z		Bezel, Right
31	26X270		Screw
32	26X238		Screw
33	094075		Bearing, Steering
34	094590E700		Dash
35	015X84		Nut
36	093007E701		Panel, Access
37	095318E701		Support, Dash
38	094013E701		Bracket, Rear Hanger
39	094085E700		Support, Left Grille
40	094007E701		Axle, Hanger
41	094084E700		Support, Right Grille
42	009X58		Bolt, Shoulder
43	690206E700		Frame, Right
44	690207E700		Frame, Left
45	094069		Container, Battery
46	1001002E701		Plate, Hitch
47	690218E700		Panel, Rear
48	094680		Cover, Level Adjustment
49	95218E700		Panel, Left Side
50	95217E700		Panel, Right Side
55	094186E700		Plate, Rear
58	165X124		Extension, Spring
59	094830 Z		Bracket
61	26X201		Screw
62	094113E701		Plenum, Cooling Air
63	15X116		Nut


Ref #	Part Number	Qty	Description
	48X069		Decal, Right Hood
	48X070		Decal, Left Hood
	44X7325		Decal, Warning
	F-99706		Book, Instruction



Ref #	Part Number	Qty	Description
1	250X68		Harness, Light Wire
	092372		Socket, Light
	090084		Bulb, Light
2	250X87		Harness, Chassis Wire
3	092556		Switch, Ignition
	020729		Key, Ignition
	091489		Nut, Hex
	091488		Cap, Ignition
4	094136		Switch, Limit
5	054212		Fuse
	407078		Holder, Fuse
6	094613		Solenoid
	26X229		Screw, Mounting
	15X116		Locknut
7	024X32		Cable, Battery Ground
	26X213		Screw, Ground Cable
8	021075		Battery
	002X82		Bolt, Carriage
	014X79		Wingnut
9	250X67		Harness, Seat Switch Wire
10	094159		Switch, Seat Sensor
11	024X31		Cable




Ref #	Part Number	Qty	Description
1	092317		Fuel Cap
2	094073		Fuel Tank
3	095197		Hose Clamp
4	023717		Fuel Line
5	095197		Hose Clamp
6	26X201		Screw
7	094006E700		Plate, Engine
8	091989		Throttle Control
9			Engine Parts are available from an Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.
	095206		Muffler
	091309		Gasket, Muffler
	095207		Adapter, Muffler
	06X103		Screw, Adapter
	009X59		Bolt, Muffler
	092378		Lock, Screw
10	0025X7		Bolt, Engine Mount
11	094593 Z		Stack Pulley Assembly
12	019X35		Lockwasher
13	01X140		Bolt, Hex
14	17X170		Washer
15	26X249		Screw
21	093349		Guide, Belt
22	015X79		Nut, Flange
23	094781		Guide, Belt
26	26X253		Screw
28	092855		Pipe, Exhaust
29	092558		Clamp
30	094324		Shield, Heat
31	26X263		Screw



Ref #	Part Number	Qty	Description
1	26X249		Screw
2	015X84		Nut, Flange
3	093349		Guide, Belt
4	094431E700		Bracket, Idler
5	015X79		Locknut
6	017X47 Z		Washer
7	094417 Z		Rod, Clutch
8	030X20		Pin, Cotter
9	094815		Adjuster
10	094045 Z		Latch, Parking Brake
11	094411 Z		Bracket Assembly, Idler
12	009X39		Bolt, Shoulder
13	094152 Z		Rod, Parking Brake
14	094185E701		Bracket, Transaxle
15	037X61		Belt
16	091179		Pulley, Idler
17	094409 Z		Arm Assembly, Idler
18	091178		Pulley, Idler
19	021544		Pedal
20	690207E700		Frame, Left
21	690206E700		Frame, Right
22	015X88		Nut, Flange
23	165X123		Spring, Extension
24	094428 Z		Rod, Disconnect
25	094429E700		Bracket, Disconnect
26	002X53		Bolt, Carriage
27	26X216		Screw
28	094432E700		Strap, Right Torque
29	094426 Z		Rod, Link
30	0031X4		Pin, Hair
31	0031X6		Pin, Hair
32	092132		Nut, Adjuster
33	094425E700		Rod, Yoke
34	165X115		Spring, Extension
35	17X169		Washer
36	094035E700		Bracket, Pivot
37	094038E700		Lever, Clutch/Brake
38	094433E700		Strap, Left Torque
39	094424 Z		Rod, Link
40	091079		Grip
41	690013E700		Pedal, Speed Control
42	17X148		Washer
43	094430 Z		Arm, Disconnect
44	165X112		Spring
45	06X105		Bolt
47	017X38		Washer
48	17X169		Washer
49			Transaxle For information on Replacement Parts see the Central Parts Distributor in your area.
50	021553		Key, Square
51	094184E701		Bracket, Right Transaxle
52	01X155		Bolt
53	165X92		Spring, Extension
54	094434E700		Clamp, Transaxle
55	17X160		Washer

---


Ref #	Part Number	Qty	Description
56	87X105 Z		Spacer
57	17X195		Washer
58	0011X3		E-Ring
59	024373		Valve Stem
60	092290-601		Wheel & Tire Assembly
61	092374		Tire
	407049		Tube
62	094618		Cap, Hub




## Mower Housing

Ref #	Part Number	Qty	Description
1	094607E701		Cover, Right Pulley
2	26X250		Screw
3	26X249		Screw
4	091754 Z		Guide, Belt
5	094645E701		Cover, Left Pulley
6	015X79		Nut, Hex
7	15X121		Nut, Flange
8	015X84		Nut, Flange
9	037X89		Belt, Primary
10	094592		Pulley
11	037X66		Belt, Secondary
12	091590		Pulley, Idler
13	94639		Arm, Idler
14	009X39		Bolt, Shoulder
15	094129		Shaft, Splined
16	091801		Pulley, Idler
17	009X52		Bolt, Shoulder
18	094068		Knob
19	017X45 Z		Washer
20	009X51		Bolt, Shoulder
21	094055E701		Bracket, Rear Suspension
22	094128E700		Plate, Suspension
23	094137		Pad, Friction
24	166X43		Spring
25	690212E700		Link, Lift
26	094600E700		Bracket, Left Lift
27	094064		Pin, Hanger
28	0031X4		Pin, Hair
29	094640E700		Brake Assembly, Left
30	094130		Spacer
31	166X41		Spring
32	030X20		Pin, Cotter
33	94641E700		Brake Assembly, Right
34	017X47 Z		Washer
35	690579E700		Idler, Arm
36	17X103		Washer
37	094606 Z		Link, Bell Crank
38	092116 Z		Guide, Belt
39	0025X7		Screw
40	165X79		Spring, Extension
41	166X42		Spring, Torsion
42	094053E701		Link, Lift
43			UNKNOWN
44	092100		Deflector, Chute
45	028X23		Push On Cap
46	166X34		Spring, Torsion
47	092159 Z		Rod, Deflector
48	092140E700		Bracket, Cover
49	165X120		Spring, Extension
50	092104E701		Bracket, Hinge
51	015X88		Nut, Flange
52	094601E701		Bracket, Bell Crank
53	094603E701		Crank, Bell
54	094596E700		Plate, Brake Arm
55	094602E701		Bracket, Brake Plate
56	094919E700		Bracket, Left Gauge Wheel

Ref #	Part Number	Qty	Description
57	094025		Axle
58	017X91 Z		Washer
59	031X11		Ring, Locking
60	092683		Wheel, Gauge
61	094918E701		Bracket, Right Gauge Wheel
62	092103E701		Deflector, Inside
63	002X53		Bolt, Carriage
64	030X49		Pin, Cotter
65	017X57		Washer
66	094997SE		Bracket, Front Deck
67	094996		Rod, Hanger
68	094604E700		Stiffener
69	690539E701		Bracket, Suspension
70	092466		Adapter, Blade
71	091925		Spacer
72	092137		Roller
73	092574		Housing, Jackshaft
74	56631E700		Blade
75	17X166		Washer, Belleville
76	15X100		Nut
77	17X165		Washer
78	94643E700		Bracket, Pulley Cover
80	019X35		Washer
81	094996		Rod, Hanger
82	26X277		Screw
83	094936E701		Housing, Blade Includes Key No. 17, 18, 30, 31, 32, 33, 45, 46, 53, 54, 55, and 56.
			Complete Mower Housing Assembly Includes items 1-83



Ref #	Part Number	Qty	Description
1	092698		Grip
2	094100 Z		Handle, PTO
3	094022 Z		Pad, Switch
4	0025X3		Bolt
5	092697		Grip
6	166X40		Spring
7	17X103		Washer
8	094195 Z		Lever, Lift
9	094017 Z		Lever, PTO
10	009X39		Bolt, Shoulder
11	030X20		Pin, Cotter
12	17X102		Washer
13	094004 Z		Link, PTO
14	015X84		Nut, Flange
15	26X249		Screw
16	166X39		Spring
17	094018E701		Bracket, PTO
18	165X120		Spring
19	94019E700		Crank, PTO
20	690212E700		Link, Lift
21	690122E700		Link, Lift Handle
22	17X158		Washer
23	017X57		Washer
24	0031X4		Pin, Hair
25	017X91 Z		Washer
26	002X85		Bolt, Carriage
27	690363E700		Lever Assembly, Lift
30	094067		Pin
31	094055E701		Bracket, Rear Suspension
32	690151		Spacer, Lifter
33	009X53		Bolt, Shoulder
34	094015E700		Bracket, Pivot
36	17X191		Washer
37	015X84		Nut, Flange
38	165X133		Spring
39	015X68		Nut, Flange
40	094005E700		Bracket, PTO
41	094027E701		Hanger, Left Deck
42	094026E701		Hanger, Right Deck
43	094158 Z		Rod, Hanger
44	690539E701		Bracket, Suspension
45	094042 Z		Stud
46	690182		Stud, Swivel
47	015X84		Nut
48	015X79		Nut



## Steering

Ref #	Part Number	Qty	Description
1	094591		Wheel, Steering
2	094127		Post, Steering
3	094131		Clip, Retainer
4	094124		Bearing
5	15X113		Nut, Flange
6	009X57		Bolt, Shoulder
7	690183		Gear, Pinion
8	011X25		Ring, Snap
9	094121		Gear, Sector
10	094123		Bearing
11	001X84		Bolt
12	690167E700		Plate, Steering
13	094006E700		Plate, Engine
14	015X88		Nut, Flange
15	15X118		Nut, Flange
16	094013E701		Bracket, Hanger
17	094007E701		Axle, Hanger
18	01X146		Bolt
19	030X49		Pin, Cotter
20	690150		Bearing
21	094576E701		Spindle Assembly, Left
22	01X111		Bolt
23	17X104		Washer
24	017X53 Z		Washer
25	015X84		Nut, Flange
26	690210E700		Axle Assembly
27	095329E701		Drag Link, Left
28	094575E701		Spindle Assembly, Right
29	095328E701		Drag Link, Right
30	26X249		Screw
31	091334		Bearing, Wheel
32	024373		Stem, Valve
33	091912		Tire
	407047		Tube
34	094579-601		Wheel and Tire Assembly
35	17X195		Washer
36	17X192		Washer
37	17X113		Washer
38	094618		Hub Cap (Optional)
39	26X267		Screw
40	092059		Bellows (Optional)