


MODEL 461004x92A

REPAIR PARTS SEAT DECK



MODEL 461004x92A


REPAIR PARTS SEAT DECK

Key No.	Part No.	Description	Key No.	Part No.	Description
1	1001028	Seat	26	094004 Z	Link, PTO
2	094154E701	Support, Seat	27	009x39	Shoulder, Bolt
3	028x23	Push-On Cap	28	017x57	Washer
4	017x47 Z	Washer	29	030x20	Pin, Cotter
5	1001054	Bolt, Wing	30	166x39	Spring
6	001x45	Bolt	31	094018E701	Bracket, PTO
7	1001648E700	Bracket, Pivot	32	166x40	Spring
8	015X89	Nut	33	17x103	Washer
9	26x229	Screw	34	690533	Handle, Lift
10	094057	Spring, Leaf	35	092697	Grip
11	164x31	Spring	36	094591	Wheel, Steering
12	094155 Z	Washer, Cup	37	091079	Grip
13	009x55	Bolt	38	092059	Bellows
14	094156 Z	Rod, Pivot	39	1001245 Z	Rod, Parking Brake
15	009x56	Bolt, Shoulder	40	26x267	Screw
16	1001555E700	Deck, Seat	41	094124	Bearing, Lower
17	26x263	Screw	42	690183	Gear, Pinion
18	164x30	Spring	43	011x25	Retainer
19	26x249	Screw	44	690625	Shaft, Steering
20	092698	Grip	45	094131	Clip, Retainer *
21	094100 Z	Handle, PTO	46	0031x4	Pin, Cotter
22	0025x3	Screw	47	15x123	Nut
23	094022 Z	Paddle, Switch	70	1001542	Holder, Beverage
24	094017 Z	Lever, PTO	—	095027	Parts Bag, Assy
25	015x84	Nut	—	F-040741L	Manual and Parts List

* NOTE: This part included with key 36.

MODEL 461004x92A

REPAIR PARTS HOOD AND DASH




MODEL 461004x92A

REPAIR PARTS HOOD AND DASH

Key No.	Part No.	Description	Key No.	Part No.	Description
1	1001593E700	Dash	20	1001814	Insert, Left Hood
2	26x270	Screw	21	1001815	Insert, Right Hood
3	1001491	Bearing, Upper Steering	22	26x263	Screw
4	26x238	Screw	23	015x82	Nut
5	093007E701	Panel, Access	24	15x124	Nut
6	095218	Panel, Left Side	25	26x201	Screw
7	095217	Panel, Right Side	26	009x47	Bolt, Shoulder
8	26x249	Screw	27	094680	Cover
9	095318E701	Support, Dash	28	094194E701	Plate, Lift Detent
11	1001812E201	Hood	29	690424	Container, Battery
12	1001813E201	Grille	30	015x81	Nut
13	1001820	Lens	31	094383	Mat, Left
14	1001819	Housing, Light	32	094382	Mat, Right
15	1001816	Insert, Center	33	1001555E700	Deck, Seat
16	1001817	Insert, Left	34	009x58	Bolt
17	1001818	Insert, Right	35	1001920-701	Shield, Heat
18	1001799E701	Bracket, Lower Pivot	59	1001755	Grommet
19	1001921E701	Bracket, Support	70	1001542	Holder, Beverage

MODEL 461004x92A

REPAIR PARTS MOTION DRIVE




MODEL 461004x92A

REPAIR PARTS MOTION DRIVE

Key No.	Part No.	Description	Key No.	Part No.	Description
1	690366 Z	Lever, Shift	31	091923	Tire *
2	092697	Grip	—	407049	Tube
3	690131 Z	Plate, Adjusting	32	094045 Z	Latch, Parking Brake
4	015x88	Nut	33	021544	Pedal
5	17x103	Washer	34	037x68	Belt, Drive
6	690130 Z	Link, Shift	35	690129 Z	Yoke, Shift
8	165x116	Spring, Extension	36	17x148	Washer, Square
9	094042 Z	Stud, Spring	37	091889	Pilot, Support
10	015x79	Nut	38	017x38	Washer
11	009x39	Bolt, Shoulder	39	06x105	Capscrew
12	015x89	Nut	40	0031x6	Pin, Hair
13	094041 Z	Rod, Clutch	41	690213 Z	Spacer, Left
14	690364 Z	Arm Assembly, Idler	42	17x118 Z	Washer
15	009x54	Bolt, Shoulder	43	030x20	Pin, Cotter
16	094815	Nut, Adjusting	44	690410	Pulley, V Idler
17	26x249	Screw	45	023339	Pulley, Backside Idler
18	690070E700	Bracket, Spring Mount	46	17x169	Washer
19	01x155	Bolt	47	165x115	Spring, Brake
20	002x78	Bolt, Carriage	48	0011x7	Ring, Retainer
21	002x53	Bolt, Carriage	49	690181	Pulley, Drive
22	26x216	Bolt	50	690080E700	Bracket, Right Torque
23	690081E700	Bracket, Left Torque	51	165x92	Spring, Extension
24	015x84	Nut	52	—	Transmission †
25	0031x4	Pin, Hair	53	024039	Key, Square
26	094618	Cap, Hub	54	690214 Z	Spacer, Right
27	011x23	E-Ring	55	165x133	Spring, Extension
28	17x193	Washer	56	690369	Spacer
29	024373	Stem, Valve	57	015x98	Nut
30	093263-601	Wheel and Tire			

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.


† For information on Replacement Parts for this transaxle contact the manufacturer.



Key No.	Part No.	Description
1	009x62	Bolt, Shoulder
2	15x111	Nut, Lock
3	015x79	Nut, Flange
4	094384	Guide, Screw
5	690146E700	Link, Left Drag
6	17x168	Washer
7	015x84	Nut, Flange
8	690145E700	Link, Right Drag
9	001x84	Bolt
10	690180	Bearing, Sector Gear
11	092530	Fitting, Lub
12	690147	Gear, Sector
13	1001121E700	Plate, Steering

MODEL 461004x92A


REPAIR PARTS FRONT AXLE



Key No.	Part No.	Description	Key No.	Part No.	Description
1	690067E700	Bracket, Rear Hanger	8	690198E700	Hanger, Left Deck
2	15x118	Nut, Flange	9	26x249	Screw
3	690232E701	Axle Assembly	10	01x146	Bolt
4	030x49	Pin, Hair	11	690179E701	Spindle Assembly, Left
5	017x75	Washer	12	094007E701	Hanger, Axle
6	093058	Bearing, Spindle	13	690199E701	Hanger, Right Deck
7	092530	Fitting, Lub	14	690178E701	Spindle Assembly, Right

MODEL 461004x92A

REPAIR PARTS FRONT FRAME ASSEMBLY




Key No.	Part No.	Description	Key No.	Part No.	Description
1	1001268E701	Frame, Right	15	17x152	Washer
2	1001269E701	Frame, Left	16	015x41	Nut
3	015x84	Nut, Flange	17	025x15	Screw
4	690182	Stud, Swivel	18	690192E701	Guide, Belt
5	690406E700	Bracket Ass'y, Suspension	19	†	Assembly, Steering *
6	030x20	Pin, Cotter	20	092644-601	Wheel & Tire Assembly
7	26x249	Screw	21	024393	Tire *
8	094006E701	Plate, Engine	—	407049	Tube
9	015x88	Nut	—	093604	Bearing, Wheel
10	094005E700	Bracket, PTO Crank	22	024373	Stem, Valve
11	002x87	Bolt, Carriage	23	17x194	Washer
12	017x57	Washer	24	17x114	Washer
13	690394E701	Crank, PTO	25	030x49	Pin, Cotter
14	094038E700	Lever, Brake/Clutch	26	094618	Cap, Hub

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

† See the Sector Gear Repair Parts page.

MODEL 461004x92A


REPAIR PARTS REAR FRAME ASSEMBLY



Key No.	Part No.	Description	Key No.	Part No.	Description
1	690094E701	Frame, Rear Hitch	13	690151	Spacer, Lifter
2	690077E700	Bracket, Seat Deck	14	002x85	Bolt, Carriage
3	26x249	Screw	15	015x79	Nut, Flange
4	015x84	Nut, Flange	16	1001302E701	Bracket, Right Shift
5	17x168	Washer	17	094384	Screw, Guide
6	690122E700	Link, Lift Handle	18	690482E701	Support, Battery
7	0031x4	Pin, Hair	19	690064E700	Bracket, Right Transaxle
8	1001111E701	Assembly, Lifter	20	1001268E701	Frame, Right
9	1001691E700	Bracket, Left Transaxle	21	1001269E701	Frame, Left
10	094015E700	Bracket, Lift Pivot	22	690365 Z	Bracket, Idler
11	009x53	Bolt, Shoulder	23	1001098E701	Plate, Stiffening

MODEL 461004x92A

REPAIR PARTS ENGINE MOUNT ASSEMBLY



MODEL 461004x92A

REPAIR PARTS ENGINE MOUNT ASSEMBLY


Key No.	Part No.	Description	Key No.	Part No.	Description
1	092317	Cap, Fuel **	25	01x140	Bolt
2	690289	Tank, Fuel	26	711851	Gasket
3	26x253	Screw	28	06x103	Bolt
6	26x229	Screw	29	690541	Tube, Right Exhaust
7	26x213	Screw	30	690542	Tube, Left Exhaust
13	*	Engine *	31	690537E700	Bracket, Muffler Mounting
14	7601033	Line, Fuel (18 inches long) **	32	093259	Muffler
15	095197	Clamp **	33	690538E700	Bracket, Muffler
16	092279	Pipe, Oil Drain	34	690401	Choke
17	021651 Z	Cap, Oil Drain	35	015x68	Nut
20	0025x7	Bolt	36	26x201	Screw
21	093077	Spacer	37	093165	Control, Throttle
22	690225	Pulley, Stack	38	1001920-701	Shield Assembly, Heat
23	17x170	Washer	39	1001588	Plenum
24	019x35	Lockwasher			

* For information on Replacement Parts for this engine contact the manufacturer.

** These parts are included with Key number 2.

MODEL 461004x92A

REPAIR PARTS ELECTRICAL SYSTEM




IGNITION SWITCH	
OFF	M+G+L
RUN 1	B+L A+Y
RUN 2	B+L
START	B+L+S

MAIN HARNESS: 250X117
REAR HARNESS: 250X67
LIGHT HARNESS: 250X92

Key No.	Part No.	Description
1	250x92	Harness, Light Wire
	1001716	Socket, Light
	090084	Bulb, Light
2	250x117	Harness, Chassis Wire
3	092556	Switch, Ignition
	020729	Key, Ignition
	091489	Nut, Hex
	091488	Cap, Ignition
4	094136	Switch, Limit
5	302031	Fuse
	407078	Holder, Fuse
6	094613	Solenoid
	26x229	Screw, Mounting
	15x116	Locknut
7	024x32	Cable, Battery Ground
	26x229	Screw, Ground Cable
8	021075	Battery
	002x82	Bolt, Carriage
	014x79	Wingnut
9	250x67	Harness, Seat Switch Wire
10	094159	Switch, Seat Sensor
11	024x31	Cable

MODEL 461004x92A


REPAIR PARTS MOWER HOUSING SUSPENSION



Key No.	Part No.	Description
1	094068	Knob
2	017x45	Washer
3	094137	Pad, Friction
5	095194	Pin, Hanger
6	690550E701	Link, Lift
7	015x84	Nut, Flange
8	009x52	Bolt, Shoulder
9	690578E701	Bracket, Rear Suspension
10	094025	Bolt, Gauge Wheel
11	092683	Wheel
12	031x11	Pin, Hair
13	017x91	Washer
14	17x103	Washer
15	030x49	Pin, Cotter
16	092159 Z	Rod, Deflector
17	028x23	Push-On Cap
18	1001252	Roller
20	094996	Rod, Deck Suspension
21	0031x4	Pin, Hair
22	26x249	Screw
23	094765E700	Bracket, Front Suspension
24	094158 Z	Rod, Hanger
25	094604E700	Stiffener
26	166x34	Spring
27	092103E701	Deflector, Inside
28	092100	Deflector, Chute

MODEL 461004x92A

REPAIR PARTS BLADE DRIVE



MODEL 461004x92A


REPAIR PARTS BLADE DRIVE

Key No.	Part No.	Description	Key No.	Part No.	Description
1	094592	Pulley	23	030x20	Pin, Cotter
2	15x140	Nut	24	094602E701	Bracket, Brake Plate
3	015x98	Nut	25	26x249	Screw
4	037x66	Belt, Secondary	26	094640E700	Brake Assembly, Left
5	037x96	Belt, Primary	27	094596E700	Plate, Brake Arm
6	690387	Pulley, Idler	28	094641E701	Brake Assembly, Center
7	015x84	Locknut	29	015x79	Nut, Flange
8	1001197	Spacer, Pulley *	30	165x79	Spring
9	690549	Pulley, Idler	31	092140E701	Bracket, Cover
10	094606 Z	Link, Bell Crank	32	094603E701	Bell Crank
11	166x41	Spring	33	092116 Z	Guide, Belt
12	165x138	Spring	34	690221E701	Bracket, Pulley Cover
13	26x270	Screw	35	091754	Guide, Belt
14	094607E701	Cover, Right Pulley	36	1001200	Ass'y, Jackshaft Housing
15	009x39	Bolt, Shoulder	37	17x166	Washer
16	094639E701	Arm Assembly, Idler	38	17x165	Washer
18	017x47	Washer	39	15x100	Nut, Blade
19	26x277	Screw	40	056631E701	Blade
20	094645E701	Cover, Left Pulley	41	690411	Adapter, Blade
21	690579E700	Arm Assembly, Idler	42	002x53	Bolt, Carriage
22	0025x7	Bolt	43	690369	Spacer

* Included with Key 36.

MODEL 461004x92A

REPAIR PARTS MOWER HOUSING



Key No.	Part No.	Description
1	009x51	Bolt, Shoulder
2	690128E701	Plate, Suspension
3	094598E700	Bracket, Right Rear
4	092104E700	Bracket, Hinge
5	166x43	Spring, Left
6	015x79	Nut, Flange
7	015x84	Nut, Flange
8	094601E701	Bracket, Bell Crank
9	015x88	Nut, Flange
10	094600E700	Bracket, Left Lifter

Key No.	Part No.	Description
11	094919E701	Bracket, Left Gauge Wheel
12	002x53	Bolt, Carriage
13	690204E701	Housing, Blade
14	094997SE	Bracket, Front Deck
15	094918E700	Bracket, Right Gauge Wheel
16	028x64	Retainer
17	002x74	Bolt, Carriage
18	166x42	Spring, Right
—	776111	Complete Mower Housing