


# MODEL 387002x92D

# REPAIR PARTS CHASSIS & HOOD




# MODEL 387002x92D

# REPAIR PARTS CHASSIS & HOOD

Key No.	Part No.	Description	Key No.	Part No.	Description
1	690566	Seat	24	092399	Bearing, Steering
2	094154E701	Support, Seat	25	26x239	Screw
3	094057	Spring, Seat	26	26x270	Screw
4	26x229	Screw	27	092331E700	Support, Dash
5	017x47	Washer	29	092815E245	Frame Assembly
6	1001054	Bolt, Wing	30	092347E701	Bracket, Left Grille
7	009x56	Bolt	31	092332 Z	Rod, Pivot
8	094156 Z	Rod, Pivot	32	092398	Bearing, PTO
9	009x55	Bolt, Shoulder	33	0031x4	Pin, Hair
10	094155 Z	Washer	34	092346E701	Bracket, Right Grille
11	164x31	Spring, Compression	35	26x249	Screw
12	001x45	Bolt, Hex	36	094107	Mat
13	1001648E701	Bracket, Pivot	37	091895	Tray, Battery
14	015x89	Nut	38	092443E245	Cap, Console
15	091724E245	Fender, Apron	39	15x123	Nut
16	092333E245	Hood	40	164x30	Spring, Compression
17	092350	Grille Assembly (includes Lens)	41	092725 Z	Clamp, Battery
18	092344	Lens	44	092448	Brace, Grille
19	009x47	Screw	45	028x23	Cap, Push On
20	092328E245	Fender	46	1001650 Z	Plate Assembly, Switch
21	1001994E245	Console Assembly	47	26x208	Screw
22	26x263	Screw	- -	F-050717L	Instruction Book & Parts List
23	070138	Dash Panel			

# MODEL 387002x92D

# REPAIR PARTS MOTION DRIVE



# MODEL 387002x92D

# REPAIR PARTS MOTION DRIVE


Key No.	Part No.	Description	Key No.	Part No.	Description
1	091754	Guide, Belt	30	092694E701	Plate, Belt Guide
2	015x84	Locknut, Flange	31	06x105	Bolt, Hex
3	015x79	Nut, Flange	33	017x38	Washer
4	01x155	Bolt, Hex	34	**	Transaxle, Peerless
5	091079	Grip	34a	020697	Woodruff Key No. 9
6	26x214	Screw	35	015x88	Nut, Flange
7	091727E701	Rod, Control -Park Brake	36	002x64	Bolt, Carriage
8	091825E701	Guide, Bracket	37	091804E701	Support, Transaxle
9	26x249	Screw	38	26x216	Screw
10	021544	Clutch and Brake Pedal	39	021553	Key, Square
11	091862E701	Lever Assembly	40	17x160	Washer
12	091808 Z	Rod, Clutch	41	690553 Z	Spacer, Transaxle
13	021920 Z	Nut, Adjustable	42	091923	Tire*
14	030x20	Pin, Cotter	--	407049	Tube
15	091713E701	Bracket, Support	43	1002046-601	Wheel & Tire Assembly
16	091712 Z	Latch, Park Brake	44	024373	Stem, Valve
17	165x82	Spring, Brake Extension	45	17x195	Washer
18	017x47	Washer	46	0011x3	E-Ring
19	092737 Z	Bracket Assembly, Idler	47	17x146	Washer
20	0011x7	Ring, Retainer	48	017x45	Washer
21	009x39	Bolt, Shoulder	49	094618	Hub Cap
22	165x76	Spring, Drive Extension	50	17x102	Washer
23	095094	Pulley, Motion Drive	51	020619	Guide, Belt
24	690409	Pulley, Backside Idler	52	092815E245	Frame Assembly
25	037x61	Belt, Motion Drive	53	092008	Ring, Tolerance
26	091995	Knob, Shift Lever	54	690369	Spacer
27	1002003 Z	Lever, Shift	55	015x98	Nut
28	091806	Yoke, Shift	56	1001755	Grommet
29	17x148	Washer			

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

\*\* For information on Replacement Parts for this transaxle contact the manufacturer.


# MODEL 387002x92D

# REPAIR PARTS STEERING



Key No.	Part No.	Description
1	094134	Wheel, Steering
2	094131	Pin, Retainer
3	011x28	Ring, E
4	1001705	Post, Steering
5	17x118	Washer
6	26x249	Screw
7	1001704E701	Bracket, Sector
8	1401099	Gear, Pinion
9	1401098	Bearing
10	001x84	Bolt, Hex
11	015x87	Locknut, Flange
12	092564	Spacer
13	1001708E701	Gear, Sector
14	091708E701	Bracket, Sector
15	1001710	Kit, Steering Gear
16	01x146	Bolt, Hex
17	092529E701	Support, Rear Axle
18	090038E701	Rod, Tie
19	030x49	Pin, Cotter
20	092527	Bearing
21	017x57	Washer
22	030x20	Pin, Cotter
23	17x113	Washer
24	091828E701	Spindle Assembly, Right
25	092518E701	Spindle Assembly, Axle & Left
26	092528E701	Support, Front Axle
27	091912	Tire*
--	407047	Tube
28	024373	Stem, Valve
29	091334	Bearing, Wheel
30	17x195	Washer
31	1001840-601	Wheel & Tire Assembly
32	092097	Bearing
33	15x113	Locknut, Flange
34	1001649E701	Link, Drag
35	01x142	Bolt
37	17x192	Washer
38	094618	Hub Cap
39	092059	Bellows
40	015x88	Locknut, Flange
41	17x168	Washer, Drag Link
42	26x267	Screw, Axle Support
43	01x194	Bolt


\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.



<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	092698	Grip
2	091781 Z	Control, Blade Rotation
3	0025x3	Bolt, Hex
4	015x67	Locknut, Hex
5	1001711E701	Lever Assembly, Switch
6	002x53	Bolt, Carriage
7	166x32	Spring, Torsion
8	092066E701	Bracket, Rear Hanger
9	015x79	Nut, Flange
10	092131 Z	Nut, Adjusting
11	092133E701	Bracket, Adjuster Rod
12	17x124	Washer
13	0031x4	Pin, Hair
14	17x122	Washer
15	090827 Z	Pin, Pull
17	091787E701	Lever, Lower Blade Control
18	1001951 Z	Rod, PTO
19	091741E701	Plate, Adjuster
20	17x103	Washer
21	092033E701	Bracket, Pivot
22	092065E701	Lifter Assembly
23	092572	Button, Push
24	092783	Grip
25	164x21	Spring, Compression
26	091823E701	Handle Assembly
27	026x49	Screw
28	092064E701	Link, Suspension
29	017x47	Washer
30	017x91	Washer
33	021920	Nut, Adjusting

# MODEL 387002x92D


# REPAIR PARTS MOWER HOUSING



# MODEL 387002x92D

# REPAIR PARTS MOWER HOUSING

<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	15x140	Nut, Hex	32	091813E701	Bracket Assembly, Left Lifter
3	092852 Z	Pulley, Jackshaft	33	165x72	Spring, Extension
4	015x84	Locknut, Flange	34	091743E701	Bracket, Pivot
5	1001703	Spacer	35	091770E701	Plate
6	037x63	Belt, Blade Drive	36	017x103	Washer
7	690387	Pulley, Idler	37	002x53	Bolt, Carriage
8	030x20	Pin, Cotter	38	094707	Deflector Assembly, Chute
9	015x88	Locknut, Flange	39	0166x4	Spring, Torsion
10	017x47	Washer	40	094956E701	Bracket, Hinge
11	092186E701	Brake Assembly, Right	41	091793E701	Bracket, Front Hanger
12	092187E701	Brake Assembly, Left	42	094957 Z	Rod, Deflector
13	166x27	Spring, Torsion	43	028x23	Cap, Push On
14	0025x7	Bolt, Hex	44	091739 Z	Rod, Hanger
15	092072E701	Bracket Assembly, Brake	45	17x124	Washer
16	091745 Z	Rod, Brake	46	092119E701	Hanger, Front
17	092183 Z	Rod, Cross Link	47	690369	Spacer
18	0031x4	Pin, Hair	48	015x98	Nut
19	092131 Z	Nut, Adjustable	49	001x84	Bolt, Hex
20	091748 Z	Rod, Adjuster	50	1001709	Housing, Jackshaft
21	021920	Nut, Adjustable	52	690411	Adapter, Blade
22	092064E701	Link, Suspension	53	095104E701	Blade, 38" (2 required)
23	17x103	Washer	54	17x166	Washer, Belleville
24	092194E701	Bracket Assembly, Right Lifter	55	17x165	Washer
25	015x79	Nut, Flange	56	15x100	Nut, Hex
26	092033E701	Crank, Bell	58	092163	Indicator, Plastic
27	009x39	Bolt, Shoulder	59	017x48	Washer
28	092032E701	Arm Assembly, Idler	60	091906E701	Housing, Blade (38")
29	091741E701	Plate, Adjuster	61	009x42	Bolt, Shoulder
30	091792E701	Cover, Pulley	1-61	403228	Complete Mower Housing Assembly
31	091797 Z	Guide, Belt			




<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	092317	Fuel Cap
2	1001752	Fuel Tank
3	095197	Hose Clamp **
4	7601033	Fuel Line (Must cut to length) **
5	095197	Hose Clamp **
6	26x201	Screw
8	1001689	Throttle Control
9	- - *- - -	Engine
9a	1001720	Muffler
9b	091309	Gasket, Muffler
9c	1001737	Adapter, Muffler
9d	06x103	Screw, Adapter
9e	009x59	Bolt, Muffler
9f	092378	Lock, Screw
10	0025x7	Bolt, Engine Mount
11	690442 Z	Stack Pulley Assembly
12	019x35	Lockwasher
13	01x140	Bolt, Hex
14	17x170	Washer
30	1001744	Shield, Heat
31	26x263	Screw
32	06x104	Screw

\*\* These parts are included with Key No. 2.

\* For information on Replacement Parts for this engine contact the manufacturer.

# MODEL 387002x92D

# REPAIR PARTS ELECTRICAL SYSTEM



IGNITION SWITCH	
OFF	G+M+L
RUN 1	B+L
RUN 2	B+L A+Y
START	B+L+S

**WIRING HARNESS FOR:**  
**PAN FRAME**  
**MAIN HARNESS: 250X143**  
**LIGHT : 250X92**

<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
1	250x92	Harness, Light Wire
	1001716	Socket, Light
	090084	Bulb, Light
2	250x143	Harness, Chassis Wire
3	1001993	Switch, Ignition
	020729	Key, Ignition
	091489	Nut, Hex
	091488	Cap, Ignition
4	091299	Switch, Limit (PTO)
	26x233	Screw, Mounting
5	302031	Fuse
	407078	Holder, Fuse
6	1002004	Solenoid
	26x229	Screw, Mounting
	15x116	Locknut
7	024x30	Cable, Battery Ground
	26x229	Screw, Ground Cable
8	021075	Battery
	002x82	Bolt, Carriage
	014x79	Wingnut
10	094159	Switch, Seat Sensor
11	024x29	Cable
12	024273	Switch, Select Reverse™
	06x119	Screw, Mounting
	015x81	Locknut
	1002001	Spacer
13	024273	Switch, Select Reverse™
	26x233	Screw, Mounting